

SB360 Sidelifter

Operation, Maintenance & Service Manual

V4.0



STEELBRO

Warranty Summary

This warranty statement is a summary of the full product warranty and does not constitute a full statement of the warranty terms and conditions.

The following warranty is given in lieu of and to the exclusion of any other guarantee, condition or warranty, either expressed or implied by statute or otherwise and whether regarding goods manufactured by ourselves or others. Provided the terms of payment are promptly complied with by you, we undertake to remedy with reasonable despatch, any original defects arising from faulty workmanship, in any goods manufactured by us, which under proper and normal conditions of use, are revealed within twelve (12) calendar months or one thousand (1000) hours of operation, whichever occurs soonest from the date of delivery, provided the defective item is returned to our Works, freight paid both ways, or in the case of the item not being returnable, then provided the expenses of travelling, transport, plant hire and accommodation are to your account.

Any goods supplied or work done in remedying such defects shall not extend our liability under this clause beyond the time stipulated above. At the expiration of such time, all further liability on our part shall cease. In the case of goods or material not of our manufacture, we shall endeavour to secure for you, the benefit of any guarantee given to us in respect thereof. In no case, shall we be liable for the cost of replacing and fitting of defective goods, and goods replaced shall become our property. No responsibility will be accepted for any defect, unless we first receive a written complaint, and we have been given first priority and ample opportunity to rectify the defect.

Liability for consequential damage or loss arising from defects, faulty materials, omissions, or negligence of workmanship, in any goods supplied by us is excluded.

Labour charges for work carried out under the terms of this warranty are to the purchaser's account.

Variations to the above are subject to STEELBRO New Zealand Limited Management approval.

Claims under warranty will only be accepted if all conditions of warranty are satisfied.



Contents

Foreword	1
----------	---

Owner and Operator Responsibilities	3
-------------------------------------	---

Regulation Compliance	3
Health & Safety Compliance	3
Maintenance and Servicing	3
Design and Modifications	3
Safety Instructions	5
Operator Safety	5
Shift Safety Practices	5
Tractor Unit Safety	5
Stabiliser Legs	6
Work Area Safety	7
Overhead Power Lines and Cables	7
Driving Safety	8
Lifting Safety	8
Crane Traverse Safety	9
Emergency Stop Button	10
Modifications	10
Hydraulic System	10

General Description	11
---------------------	----

Commissioning Checks	12
----------------------	----

Commissioning the Sidelifter	13
------------------------------	----

Main Components	15
-----------------	----

Main Components Fixed Module Models	17
Chassis, Suspension & Axles	17
Stabiliser Legs	18
Proximity Switches (units without SMARTlift only)	19
Ground Pressure	19
Stabiliser Interlock System	20
Bending Leg Option - for SB360, SB361 and SB401	22
Crane Lifting Modules	25
Over-Centre Valves	25
Lifting Chains - Clevis Hook (SB330, SB360, SB361 and SB401)	26
Lifting Chains - Oblong Link/Top Hook (some SB330's and SB360's)	27
Lifting Lug Instructions	29
Using the Container Lifting Lugs	29
Power Pack	30
Electrical System Power Pack Version	33



System Lay Out.....	33
System Operation	33
Electrical System - PTO Version.....	34
System Layout.....	34
System Operation	34
Hydraulic System - Power Pack Version	35
System Control.....	35
System Operation	35
High Speed Load Sense (LS) Unloader Valve Logic.....	36
Hydraulic System - PTO Version.....	37
System Control.....	37
System Operation	37
Pneumatic System	37
Hold Back Protection Valve.....	38
Crane module locks (applies to R&P Traverse only)	38
Engine Speed Control	38
Engine Run/Stop Control	38
Self Steer Axle (if fitted).....	38

Crane Operations 39

Operating Near Power Lines	39
Contact with Power Lines (Aerial Conductors)	40
Crane Module Operation - Cable Control	41
Positioning the Lifting Cranes.....	42
Lifting a Container From The Ground	45
Placing a Container on The Ground	47
Transferring Containers to and from a Truck or Trailer.....	48
Transferring 20' Containers to and from 20' Trailers or 40' Containers to and from 40' Trailers.....	48
Transferring 2 X 20' Containers To and From 40' Trailers	48
Double Stacking Containers	49
Double Stacking - lifting container from sidelifter to place on top of another container.	49
Unstacking - lifting top container back onto sidelifter.	50
Chain Shortening Instructions 20mm Chain	50
Chain Shortening Instructions 16mm Chain	51
Transferring Containers to & from Rail Wagons	53

Recommended Companion Vehicles 55

Maintenance 57

Why Genuine Parts?	57
Preventative Service	57
Grease and Oil Specifications	57
Servicing Trailer Running Gear	58
Records.....	58
Daily Inspection Requirements	58
Hydraulics	58
Lifting Gear and Chassis.....	59
Brakes - Air Pressure Systems	59
Lights	59
Wheels and Tyres	59
Suspension	60
Weekly Inspection and Service Requirements	61
Chassis	61
Lifting Modules.....	61



Landing Legs.....	61
Monthly Inspection and Service Requirements.....	61
Hydraulic System and Chassis	61
Brakes - Air Pressure Systems	62
Lights	62
Wheels and Tyres.....	62
Six Monthly Inspection and Service Requirements.....	62
Hydraulic System	62
Chassis	63
Suspension and Axles (As detailed in the suspension and axle manuals)	63
Annual Inspection and Testing	63
King Pin	63
Lifting Chains	64
Lifting Equipment	64
Overload Test.....	64
Testing after repairs to the cranes.....	64
Maintenance Notes	64
Pressure Line Filter:	64
Return Line Filter:.....	64
Filler Breather:	65
Emergency Instructions in Case of Electrical Faults:.....	65
Precautions with Over-Centre Valves and Check Valves	65

Notes On Tractor/Semi Trailer Operation	67
--	-----------

Coupling and Uncoupling.....	67
Experience Counts	67
Chief Cause of Trouble	67
Simple Checking Devices For Semi Trailers.....	68

Index	69
--------------	-----------



Foreword

This Operators Manual deals with your new STEELBRO Sidelifter. Take the time to read it through - it will be time well spent. The manual contains a short description of the Sidelifter together with instructions on its operation and maintenance. Generally this manual is provided along with other documentation including manuals provided by third party manufacturers, parts lists, technical drawings and schematics and compliance certification, either in bound print format, in a folder, or on a data CD.

If you wish to ensure a long life for your Sidelifter, you should carefully carry out all the maintenance instructions. However, all servicing, apart from lubrication and minor repairs should wherever possible be entrusted to factory trained service facilities.

We reserve the right to introduce, without notice, changes in data and equipment and amendments to the instructions for maintenance and other servicing work.

In this document:



This symbol means that the instruction in the shaded area is essential to the safe operation of your Sidelifter and failure to follow the instruction is likely to lead to injury or damage to property



This symbol means that the instruction in the shaded area relates to safe or recommended practice and failure to follow the instruction could lead to damage or accident.



This symbol means that the information in the shaded area is useful and/or is something we wish to emphasise.



Owner and Operator Responsibilities

Regulation Compliance

It is the responsibility of the OWNER to ensure that use of the Sidelifter fully complies with all Local Authority, State and Government Regulations covering lifting equipment, road use, health and safety in the country where the Sidelifter is being used.

Health & Safety Compliance

The OWNER must provide and maintain work environments, systems of work, and his equipment that is, as far as practicable, safe and without risks to health.

The OWNER must ensure that only properly trained and approved operators use the Sidelifter. In some locations, the law requires an operator's Certificate of Competency. The OWNER must ensure that he complies in full with such requirements.

Operators must consistently demonstrate:

1. Healthy and safe work practices.
2. Medical and mental fitness for the task.
3. A sound knowledge of emergency procedures.
4. A sound knowledge of the contents and requirements of the STEELBRO Manuals.

If there is a hazard to health or safety that cannot be eliminated, the OWNER must immediately cease using the Sidelifter and contact STEELBRO for advice.

Maintenance and Servicing

The OWNER should realise that the reliability, safety, and longevity of the Sidelifter depends greatly on the standard of maintenance and servicing that it receives during its working life. The Maintenance and Servicing Schedules set out in the STEELBRO Manuals must be met, and ONLY suitably qualified technicians should carry out this work.

Design and Modifications

Where STEELBRO notify that a modification is required, it is the responsibility of the OWNER to ensure that the modification is carried out in accordance with the instructions from STEELBRO and if requested, to withdraw the machine from service until the modification has been carried out.

The OWNER should withdraw the Sidelifter from use where any deficiencies are identified during inspection of the Sidelifter which may affect its safe operation, until the design or operational deficiency is rectified.




The OWNER should ensure that neither the Sidelifter nor any of its components are used beyond their design capacity. For crane design capacity refer to the Safe Working Load decal and for the chassis design capacity (when applicable) refer to the Chassis plate decal. Print copies of both of these are included in the Manual.

Particular care should be taken to ensure that the emergency stop controls are always operational.



Safety Instructions



It is the responsibility of the Owner to ensure that a STEELBRO Sidelifter is only operated by an operator:

Who is well trained, mentally alert and physically prepared

Who is working under safe conditions in a comfortable environment

Utilising a properly maintained and inspected machine in a safe manner.

Has knowledge of operational and safety measures before operating the Sidelifter.

Operator Safety

Do not wear radio or music headphones while operating the Sidelifter.

In case the operator becomes unable to continue crane operation due to injury or illness, the Sidelifter must be stopped immediately and the fact must be reported to a responsible person. All operations must be disabled until it has been established whether the Sidelifter caused the injury or illness and the Sidelifter has been assessed as suitable for service.

Back care is important. Take all reasonable precautions wherever bending down or manual lifting is required. This includes changing tyres.

All Sidelifter operations may be carried out at ground level. DO NOT climb onto the crane structure. For maintenance or other operations that require 'working at height' refer to appropriate regulations.

Shift Safety Practices

For the first lift of a working shift and the first lift of each shift where the load is greater than 50% of the rated capacity, the load must be raised a short distance to test the system before continuing the operation.

At the end of a working shift the Sidelifter should be left in a safe condition in a designated parking area and reasonable precautions taken against unauthorized operation. "Safe Condition" is defined as power supply turned off and if unladen with cranes fully stowed. If laden, the container/s should be properly loaded onto the twistlocks, not suspended in any way.

Tractor Unit Safety

A Sidelifter should not be operated unless a tractor unit is coupled to it for stability purposes.

Always apply the vehicle park brake before operating the Sidelifter.

Never overload axles.

Regularly check tyre pressure. Improper pressure decreases road hold and increases tyre wear.



When some tractor unit park brakes are applied, they stop the provision of air to the Sidelifter. As the Sidelifter with engine-driven power-pack requires an air supply to operate, the application of the Sidelifter park brake may be necessary in some vehicles, rather than the tractor park brake, to maintain sufficient air supply for the Sidelifter to operate.

Stabiliser Legs



Always deploy the stabiliser legs before operating the cranes. Check that the feet have a firm surface sufficient to withstand the combined weight of the Sidelifter and load, which could be as much as 25 tonne per foot, before commencing any lifting or unloading.



The stabiliser legs must **NEVER** be operated when the Sidelifter cranes are under load.



Work Area Safety



= Yellow Area

= Red Area

During operations unauthorised personnel **MUST** keep out of the working area of the Sidelifter as shown in the Dangerous Zone Warning decal.

Always keep the Sidelifter clean and keep loose parts stowed away securely. (Use toolbox provided for this specific purpose)

Never walk or stand below a suspended load.

Never leave the Sidelifter unattended with the load on the hooks and/or the operation controls enabled.

When transferring containers to or from other vehicles the operator must not stand between those vehicles. He should operate from the end of the companion vehicle. Refer to Lifting Safety (on page 8) for more information on the recommended operating areas.

Overhead Power Lines and Cables

Do not operate the Sidelifter close to power lines or cables.



Driving Safety

Never drive with a suspended load.

Never use the cranes to drag a container along on the ground.

Always check that the stabiliser legs are fully retracted, the cranes stowed in the low folding position and that nothing is protruding beyond the width of the vehicle before driving away.

Always ensure the twistlocks are locked prior to driving away.

While driving always pay attention to the road conditions and adapt driving style to suit.

Take extreme care when approaching and taking turns. The huge inertia mass of the Sidelifter and its tendency to go straight could cause a sideways skid of the whole unit, particularly on a slippery road surface. Road train drivers should take special care.

Take particular care when reversing the Sidelifter.

Unladen Trombone machines should only be driven with the chassis in the retracted position.

Lifting Safety

This STEELBRO Sidelifter is designed to lift from one side only. Do not lift any load beyond the centre-line of the Sidelifter onto the 'non-lifting' side, referred to in this document as the 'offside'. Do not attempt to lift a container from the offside.

Never exceed the maximum capacity stated on the Safe Working Load Chart for your unit.

Always ensure the twistlocks are unlocked prior to commencing lifting operations.

With Sidelifters that traverse to handle different container sizes, lifting is only permitted when the crane modules are placed into the set lift positions.

Lifting lugs are left hand and right hand and must be used in their correct positions. Ensure that lugs are fitted according to the instructions in this manual: Lifting Lug Instructions (on page 29)


Do not lift containers from the top lifting points without the use of a STEELBRO top-lifting frame.

When ISO Tanktainer containers are being charged or discharged, the engine must be **SHUT DOWN** and the battery isolating switch turned **OFF**. When ISO Tanktainers are being loaded or unloaded from the Sidelifter ensure that **ALL TANKTAINER VALVES ARE SHUT**.




The Sidelifter Operator must have a full view of the load during the lift and if required sufficient competent persons must be available to assist. The recommended operating area is shown below:

Offside



Lifting Side






This is a view from above. Operator stands on the lifting side at least 2metres back from the rear of the sidelifter where he has a clear field of vision of both the lifting side and rear of sidelifter. This position is also recommended for transfer to or from a companion vehicle

Offside



Lifting Side



For transfer to or from a railway carriage, the recommended Operating Area is at least 2m back from the rear of the sidelifter, close enough to the gap between the sidelifter and carriage to be able to see both.

Crane Traverse Safety

Sidelifters that handle different sized containers by moving the crane modules, must have all arms and stabilisers in the stowed position when the crane modules are moved. The modules **MUST NEVER** be moved with crane modules loaded or Arms/Stabilisers extended.



Emergency Stop Button

In an emergency, depress the emergency stop button on the remote control, until the engine has stopped.

As an extra precaution, and if it is safe to do so, turn off the engine key switch on the main control panel.

Modifications

No modification may be carried out on the Sidelifter without written authority from STEELBRO.

Hydraulic System

Always ensure when disconnecting hydraulic tubing and hoses that there is no hydraulic pressure in the line before switching off the power supply to the system.



General Description

STEELBRO Sidelifters are able to load ISO containers to and from:

- The ground
- Truck decks
- Other trailers
- Rail wagons, and
- Stacked two high (units with chain shorteners)

Because the STEELBRO Sidelifter lifts the container using chains and lifting lugs attached to the bottom container corner castings, it is ideal for handling tanktainers and containers that do not have forklift pockets.

Sidelifters are available with different lifting capacities and also in different mounting configurations.

The three main types covered by this manual and their main components are detailed separately in the following sections of this manual.



Commissioning Checks

Prior to operation of your new Sidelifter, make the following checks:

- Examine the Sidelifter, checking that the specification is as ordered.
- Check for any damage to exposed equipment that may have occurred during the delivery journey (lights, mudguards, bodywork etc.).
- If the battery and night work lamps have been stowed in the toolbox for security purposes during shipping, then these need to be fitted. Ensure that the battery has sufficient electrolyte and is fitted with negative terminal to earth.
- Check tractor unit turntable compatibility to ensure safe coupling of the kingpin to the tractor unit and fitting of any kingpin blocks in the case of fifth wheel couplings mounted on oscillating 5th wheels.
- Lubricate the tractor coupling; trailer upper fifth wheel plate and kingpin with a good grease (hub grease is ideal). Couple and uncouple the Sidelifter to ensure the coupling lock operates freely.
- Connect up brake hoses and see that couplings are seating correctly. Listen for air leaks. Check brake operation. Ensure spring brakes have had the release bolts removed.
- Check tractor unit electrical coupling and layout compatibility, ensuring proper operation of clearance marker lights, brake lights and indicator lights.
- Ensure tyres are inflated to correct pressure.
- Examine axle alignment for any damage during delivery journey.
- Check axle oil level in hubs if oil filled hubs fitted.
- Ensure landing legs wind up and down while trailer is coupled to tractor.
- Check dry thread torque settings:

Wheel nuts 10 stud	375 - 400 lb.ft (550 - 600 Nm)
Wheel nuts 5 spoke	180 - 200 lb.ft (245 - 275 Nm)
Suspension "U" bolt nuts	375 - 400 lb.ft (510 - 540 Nm)
Rocker shaft nuts	215 - 260 lb.ft (294 - 353 Nm)
Radius rod fixing bolts	215 - 260 lb.ft (294 - 353 Nm)
Radius rod pinch bolts	75 lb.ft (103 Nm)
Drop out bolt	35 lb.ft (49 Nm)

- Check that Hydraulic oil level is between "Min" and "Max" levels as indicated on the hydraulic reservoir sight glass with all crane lifting modules and stabiliser legs fully stowed at the 20' position.
- Ensure sufficient engine oil and engine coolant is in the Power Pack engine when fitted.



Commissioning the Sidelifter

1. For cable remotes, connect the remote control lead from the Sidelifter control cabinet to the remote control box.
2. Clean down the area where the module slides over the chassis top flanges with a clean dry cloth.
3. Start the engine in the following sequence:
 - Check the tractor unit is correctly coupled with the park brake applied.




In tractor/trailer combinations where the trailer parks on spring brakes, the park brakes when applied stop the provision of air to the semi-trailer from the tractor. The Sidelifter requires an air supply to retract the crane module locking pins and operate the engine stop and speed control. There is normally enough air stored in the trailer system when it is parked to provide this for a reasonable number of applications. However it is essential that the Sidelifter brake system and piping are always free from air leaks, which waste the stored air. On systems where parking is performed by applying air pressure to the service lines this does not apply.

- Ensure all the Emergency stops are released and remote control (cable or radio) is working.
- Insert the key into the Sidelifter start switch and turn to the preheat position. Hold the key in this position until the amber preheat lamp beside the key switch goes out.



Pre-heating the engine is only necessary when the engine is cold.


- Turn the key to the start position. When the engine starts release the key.
4. If the lifting chains have been stowed in the toolbox during shipping then these need to be fitted as follows:
 - On the remote control, select Legs, and place the feet on the ground.
 - Select High speed () and raise the bottom arms to their maximum.
 - For Clevis pins, attach the hammerlocks of the chains to the Clevis. For chains with an oblong link, fit the oblong link over the G pin.
 - Raise the top arms until the chains hang freely in the air.
 - Check that the lifting lugs, which are left and right handed, are correctly positioned, i.e. ensure that the left and right lifting lugs are in their correct positions. If not, lower the top arm, and reposition. Raise the top arm and check lug position is now correct.



- Return the lifting arms to their stowed position ensuring the lifting chains are in the chain trays beside the twistlocks.
5. Move each lifting module independently from the delivery position to the opposite end of its traverse. Clean down chassis surfaces along where the lifting module moves.
- Shut down the engine by turning off the remote control or pressing any of the red emergency stop buttons on remote control box. Turn off the key ignition.
 - Always turn off the radio control when not in use.



Main Components



The main component systems of the Sidelifter are:

1. Chassis, Suspension and Axles
2. Crane Lifting Modules
3. Stabiliser Legs
4. Hydraulic System
5. Power Pack and Control System (if fitted)
6. Lifting Accessories (see "Crane module locks (applies to R&P Traverse only)" on page 38)
7. Pneumatic System
8. Electrical System


This type of sidelifter has at least one traversing module and can carry one 20 foot, one 40 foot or 2 x 20 foot containers.

All that is necessary for operating the sidelifter is a tractor unit of sufficient size, with compatible braking, electrical and kingpin couplings.

Sidelifters running on a Power Take Off (PTO) system, require a tractor unit with a PTO unit, pump and hydraulic coupling.



Main Components Fixed Module Models



The main component systems of the Fixed Module Sidelifter are:

1. Chassis, Suspension and Axles
2. Crane Lifting Modules
3. Stabiliser Legs
4. Hydraulic System (position may vary)
5. Power Pack and Control System (if fitted - position may vary)
6. Lifting Accessories
7. Pneumatic System
8. Electrical System

This type of sidelifter has fixed modules and carries 20 foot ISO containers.

All that is necessary for operating this sidelifter is a tractor unit of sufficient size, with compatible braking, electrical and kingpin couplings.

Sidelifters running on a Power Take Off (PTO) system, require a tractor unit with a PTO unit, pump and hydraulic coupling.

Chassis, Suspension & Axles

Parts of this chassis are fabricated from high tensile steel and must not be welded without authority from STEELBRO or its authorised service representative.


The standard Kingpin is a 2" S.A.E. removable (bolt in) type.

Two-speed wind up landing legs are fitted behind the gooseneck.

The brand, style, maintenance and servicing of this Sidelifter's axles and suspensions are detailed in separate sections of this manual.



Stabiliser Legs



The stabiliser legs are continuously welded box sections constructed from high tensile steel. The pins are mounted in glacier bearings.

The versatility of the STEELBRO Sidelifter stabiliser legs greatly assists the transfer of containers to or from other vehicles.

By being able to extend the leg, then tilt the leg, or tilt the leg, then extend the leg, gives the operator several options.

- The legs can be placed on the ground either:
 - At maximum outreach, or,
 - In a close-in position, or,
 - Underneath the deck of a companion vehicle.
- The legs can also be placed on the deck of a companion vehicle.

Sidelifters with bending Stabiliser legs have the extra versatility of being able to work at a close in position with a companion vehicle while maintaining a greater maximum safe working load. These are documented separately.



NEVER operate the Sidelifter without first deploying the stabiliser legs.

Proximity Switches (units without SMARTlift only)

Proximity switches are mounted on the stabiliser housing. These switches signal warning lights on the remote control and main control panel to indicate the stabiliser leg is tilted beyond the point of ideal stability. This warns the operator that stability has been reduced, and therefore lifting should not take place unless it is for the restricted loads shown on the lifting diagram.



NOTE: These lights may be activated when a stabiliser foot is placed into a hollow or a descending slope. In such cases it is necessary to build up the ground level by placing timber (dunnage) under the relevant stabiliser foot in order to restore full lifting capacity.

Ground Pressure

STEELBRO can only give figures based on the Rated Load Lifting Capacity of the Sidelifter. The fact that Sidelifters can lift heavier loads because of their built in Safety Margins must also be considered by designers when designing surfaces on which a Sidelifter will stand during its operations. Based on the Rated Load Lifting Capacity of the Sidelifter, and allowing for the 60/40-ratio load imbalance of containers the ratings are:

Model	Weight of box at Max SWL*	Load per Foot (tonne)	Ground Pressure (MPa)
SB300	30	20	1.3
SB330	33	22	1.3
SB360	36	23	1.3
SB361	36	24	1.3
SB401	40	26	1.7
SB121	12	10.5	0.85
SB180	18	14	0.85
SB200	20	15	0.85
SB250	25	18	0.85
SE400	40	31	1.5

*SWL= Safe Working Load.



Where the pre-operational risk assessment reveals the presence of cellars, underground services, ducts or the like, a competent person must assess whether the ground is stable enough to support the load of the stabiliser foot.

Stabiliser Interlock System

The Stabiliser Interlock system prevents lifts from being attempted without the stabilisers being deployed. A plunger switch fitted to the stabiliser housing is activated when the foot has positive downward pressure. Until that time the lifting arms are disabled.

All Sidelifters with the SMARTlift control system have this functionality, as do SB360 sidelifters in Australia.



NEVER move the stabilisers with any load on the arms. This is highly dangerous. If the stabilisers lift off the resting place during a loading operation, the correct action is to move the load back over the stabilisers before manoeuvring the load back over the trailer, keeping the distance between the bottom of the load and the twistlocks as small as practicably possible. If the stabilisers continue to lift then first return the load to the ground before deploying the stabilisers further in order to increase foot pressure.

Operation

When the unit is started up, a warning beeper sounds and a warning light on the crane illuminates until both stabilisers are deployed.

The 'top arm up' and 'bottom arm down' functions are disabled until there is a positive downward pressure on the stabiliser foot.

If during a lift the stabiliser foot loses contact with its resting place, the warning will resume and the 'top arm up' and 'bottom arm down' functions are disabled until the foot again makes contact.




NEVER move the stabilisers with any load on the arms. This is highly dangerous. If the stabilisers lift off the resting place during a loading operation, the correct action is to move the load back over the stabilisers before manoeuvring the load back over the trailer, keeping the distance between the bottom of the load and the twistlocks as small as practicably possible. If the stabilisers continue to lift then first return the load to the ground before deploying the stabilisers further in order to increase foot pressure.



System Logic	Warning Buzzer and Light	Relay (no)	Top Arm Up	Top Arm Down	Bottom Arm Up	Bottom Arm Down
Both Stabilisers touching the ground	NO	CLOSED	YES	YES	YES	YES
Either or both Stabilisers off the ground	YES	OPEN	NO	YES	YES	NO



Bending Leg Option - for SB360, SB361 and SB401






Close up of the Ankle which gives the Bending Leg Stabiliser its versatility.

The STEELBRO Bending Leg Stabiliser has the same lifting capabilities as the standard stabiliser, while also giving superior stability in situations where the stabiliser foot is placed close in to the sidelifter. This allows the sidelifter to be positioned close to railway wagons and trailers, as the ankle can fit underneath.

The stabiliser can be deployed:

1. With the Ankle fully retracted and the foot resting on the ground giving the same stabiliser outreach as a standard stabiliser.
2. On the deck of a rail wagon or trailer, with the Ankle fully retracted, the same way as with a standard stabiliser.
3. With the Ankle fully extended / rotated and the stabiliser housing fully tilted giving the same reach and stability as a standard stabiliser. This ankle position should only be used for the purpose of getting up close to railway wagons or trailers.






How to Operate the Bending Leg


The extension and retraction of the bending leg "ankle" is operated from the remote control. It is essential that the operator follow the instructions below.

Ankle Mode:	
Extend Bending leg ankle	Joysticks Up
Retract Bending leg ankle	Joysticks Down
Extend Stabilisers	Joysticks Out
Retract Stabilisers	Joysticks In





Lifting can only take place when the bending leg ankle is either fully extended or fully retracted. NEVER attempt to lift on the bending leg ankle when it is not fully extended.

Follow these steps to deploy the front and back Bending Leg Stabilisers.

1. Tilt the legs over as far as possible.
2. Switch the remote to Ankle Mode (on the SB360 this is shown by the  symbol).
3. Start extending the Ankles by pushing both joysticks directly upward.
4. As the Ankles start to curve round into position, extend the stabiliser extensions by pushing the joysticks at an angle between the extend positions (North West on the left joystick and North East on the right, relative only to the remote itself of course) until the ankles are fully extended and the feet placed on the ground.
5. If necessary, adjust the position further, ensuring that both feet are on a firm, flat surface. If a foot is not at the correct angle, a warning will go off as discussed in the following section.



Retracting the Bending Leg Ankles

1. Set the remote to Ankle mode/ .
2. Begin retracting the stabiliser housings by pushing joysticks in.
3. Once the feet have left the ground, begin to retract the ankles by pushing joystick down, watching for edges that an ankle or foot may get caught on.
4. Once the stabiliser extensions and ankles are fully retracted, switch to Stabiliser mode/  and return the legs to their retracted position.


Safety Controls - SB361 and SB401 only



NEVER apply any load to the foot before the Ankle is either fully extended, or fully retracted! This is to prevent serious damage to the construction that will consequently result in an unstable/unsafe operation.

If the ankle is not fully extended and you try to switch out of Ankle mode, an alarm will sound and the warning below will appear on the display screen until you complete the deployment of the ankle.

FRONT ANKLE NOT EXTENDED ENOUGH 71




RETURN TO MAIN MENU



NEVER apply any load to the rear joint of the Ankle. This will damage the construction and consequently result in an unstable/unsafe operation.

If the stabiliser leg is tilted at too shallow an angle, the result is the back joint of the ankle touching the ground as shown in the screen display below. Therefore, if the stabiliser housing is not angled steeply enough, the controls for the Ankle Mode are locked out and attempting to use them will result in the alarm sounding and the warning screen displaying as below.



Crane Lifting Modules

The crane modules and lifting arms are continuously welded box sections constructed from high tensile steel.

The pins are mounted in replaceable lubricated glacier bearings.

Over-Centre Valves

The hydraulic system is fitted with pilot operated over-centre valves on the crane arms which are preset at the factory to cope with all foreseen shock loads or attempts to lift more than the crane's rated Safe Working Load.

The over-centre valve:



- Prevents the arms from moving unless there is a pressure signal from the main hydraulic valve,
- Helps keep the movement of the load controlled and constant when being lowered, regardless of the pressure that may be in the cylinder,
- Ensures that the cylinders are held in position, should the hydraulic system lose pressure. This stops the arms from dropping and thus preventing any run away of the load in the event of a hose failure.


Lifting Chains - Clevis Hook (SB330, SB360, SB361 and SB401)

The Clevis Hook lifting chain assemblies for 16mm and 20mm chain slings are illustrated below. The chains, clevis hook, shorteners and lugs are all individually tested then the whole sling tested and certified. They should never be welded in any way and should be replaced should there be any sign of distortion, excessive wear or damage. Shorteners are included in chain slings where the unit is capable of stacking containers two high. Instructions for their use are in the section Chain Shortening Instructions.




Never switch chains from one machine to another as they may vary between one Sidelifter and another in length and size.

Chains should be proof tested annually. STEELBRO recommends that the inspection certificates supplied be retained for history.



16mm Chain Sling Assembly



20mm Chain Sling Assembly (SB401)

Lifting Chains - Oblong Link/Top Hook (some SB330's and SB360's)


The Oblong Link or Top Hook lifting chain assembly is illustrated below. The chain slings are tested and certified. They should never be welded in any way and should be replaced should there be any sign of distortion, excessive wear or damage. When handling the top hook, take care to place it on the lifting pin with the left and right chain legs in their correct position, and facing towards the container. Shorteners are included in chain slings where the unit is capable of stacking containers two high. Instructions for their use are in the section Chain Shortening Instructions.



Never switch chains from one machine to another as they may vary between one Sidelifter and another in length and size.

The Hammerlocks are equipped with a stress pin linkage. Any sign of the Hammerlocks not being able to fold fully means that the chain assembly has been subjected to excessive stress. In such cases the chain should be sent to an approved testing facility, for re-certification and replacement of all damaged parts.


Chains should be proof tested annually. STEELBRO recommends that the inspection certificates provided with the manual be retained for history.



Oblong Link Chain Assembly



Lifting Lug Instructions




The only, but significant, difference between a left-hand Lug and a right-hand Lug is the position of the roll-pin (marked in black above), which prevents the lug from accidentally falling out of the container-corner-casting. When standing in front of the container, facing the container, the container-corner casting at your left-hand-side is the Left Hand Container Corner Casting.




Only ever use the correctly handed lifting lug to corner casting i.e. the left lug to the left corner casting and the right lug to the right corner. Failure to do this may result in the container coming loose during a lift with obvious potentially fatal results.

Using the Container Lifting Lugs



1. With the clevis of the lug facing out from the container, position the lug in the corresponding container-corner-casting-cavity.





2. Rotate the Lifting Lug over the top of the lug until the rollpin prevents it from rotating any further.

3. The clevis is now pointing IN-wards, under an angle of approximately 60 degrees "UP". The rollpin prevents the lug from accidentally falling out of the container-corner-casting.



4. When lifting the container, the lug will slide to the top of the container-corner-casting-opening, and in a slightly steeper angle (this to prevent the rollpin from taking any real load), before lifting the container.

The slope of chain legs ensures that the lifting lugs stay locked inside the container castings during the lift cycle.



Using the Sidelifter lifting chains instead of appropriate lifting accessories for handling non-ISO container items, or for top lifting of ISO containers, will cause severe damage to the machine, and place personnel at risk. Any such action will void our warranty.

Power Pack

The power pack is a Kubota V2203 Diesel Engine. This engine develops approximately 40 horsepower at 2800 rpm and the motor speed is governed to the required pump speed of 2800 rpm.

The power pack control panel is within a weatherproof cabinet, located either on the side or the rear of the machine.

The electric start key and switch are situated on the control panel, as are any or all of the following:



- Hour meter, water temperature and oil pressure gauges,
- Generator and pre-heat warning lamps,
- E-stop circuit lamp and a glow lamp,

depending on the model and control system.



Electrical System Power Pack Version

The electrical system consists of the following:

- A 12-volt supply from the engine alternator system
- A main junction box mounted in a cabinet located at the rear of the chassis
- 2 crane module mounted junction boxes.
- One chassis mounted junction box adjacent to the power pack
- Remote control/s - cable, radio or both according to customer specification.
- A chassis mounted junction box for the SMARTlift control system, if fitted.

System Lay Out

Electrical power is supplied from the Kubota alternator system to the main junction box. The cable remote is plugged into this junction box (for radio control the receiver unit is plugged into this junction box). The main junction box is connected to the chassis mounted junction box and the two crane mounted junction boxes. If SMARTlift control is fitted, it is located on the chassis between the main junction box and the crane mounted junction boxes.

System Operation

The main control box is equipped with a key/starter switch, oil and alternator warning lamps, water temperature gauge, glow plug indicator lamp and an hour meter.

When you turn the key, the 12 volt system is energised and the run stop control (solenoid pneumatic actuated air cylinder) moves to the run position, providing the trailer air system is fully charged. The engine can now be started. Movement of the joysticks signals the engine speed control (solenoid pneumatic actuated air cylinder) to maximum speed. When the joysticks are returned to their neutral position the engine speed returns to idle after approximately three seconds. (A timer unit is fitted in the main junction box and set to three seconds to give this delay).

The remote control is equipped with two joysticks to operate all hydraulic functions. A function selector switch allows selection of stabiliser legs, crane arms, and for units with crane traverse function, crane traverse. This allows joystick signals to be transmitted via relays in the main junction box directed to the Danfoss control valves and function diverter valves via the crane mounted junction boxes. The joysticks also incorporate micro switches that independently signal the dump solenoid relay and the "PVEM power relay" (powers up the Danfoss control valve coils). There are more details on how to use the remote control to operate the cranes in the Section: Crane Operations (on page 39).

Also mounted in the remote control is a two-position switch for "High Speed" and "Low Speed" selection. When "High Speed" is selected, two relays in the main junction box are activated, one to direct joystick signals to the Danfoss control valve coils, the other to activate the "High speed load sensed unloader valve" solenoid coils. When "Low Speed" is selected these unloader valve relays are de-energised and the joystick signals are now directed via the E.H.F's. (Electronic Hydraulic flow controllers) to the Danfoss control valves. An emergency stop button ("Mushroom" type) is fitted to the remote control to shut down all systems in an emergency.



Electrical System - PTO Version

The electrical system consists of the following:

- A 12 or 24 Volt power supply from the front chassis services panel
- A main junction box mounted in a cabinet located at the rear of the chassis
- Two crane module mounted junction boxes
- One cable remote control and/or radio remote control
- A chassis mounted junction box for the SMARTlift Control system where fitted
- Electro hydraulic coils for a crane control valve

System Layout

Electrical power is supplied from the front services panel to the main junction box. The cable remote is plugged into this junction box (for radio control the receiver unit is plugged into this junction box).

The main junction box is connected to the two crane mounted junction boxes. If the Smartlift Control system is fitted, it is located on the chassis between the main junction box and the crane mounted junction box.

System Operation

The remote control is equipped with two joysticks to operate all hydraulic functions. A function selector switch allows selection of stabiliser legs, crane arms, and for units with crane traverse function, crane traverse. This allows joystick signals to be transmitted via relays in the main junction box directed to the Danfoss control valves and function diverter valves via the crane mounted junction boxes. The joysticks also incorporate micro switches that independently signal the dump solenoid relay and the "PVEM power relay" (powers up the Danfoss control valve coils). There are more details on how to use the remote control to operate the cranes in the Section: Crane Operations (on page 39).

Also mounted in the remote control is a two-position switch for "High Speed" and "Low Speed" selection. When "High Speed" is selected, two relays in the main junction box are activated, one to direct joystick signals to the Danfoss control valve coils, the other to activate the "High speed load sensed unloader valve" solenoid coils. When "Low Speed" is selected these unloader valve relays are de-energised and the joystick signals are now directed via the E.H.F's. (Electronic Hydraulic flow controllers) to the Danfoss control valves. An emergency stop button ("Mushroom" type) is fitted to the remote control to shut down all systems in an emergency.



Hydraulic System - Power Pack Version

The hydraulic system consists of the following;

- Hydraulic oil reservoir with return oil filter and a breather assembly
- Direct coupled tandem hydraulic pump
- High speed load sensed unloader valve assembly
- High-pressure oil filter.
- Two Danfoss proportional control valves.
- Four hydraulic cylinders fitted with double check valves operating the stabiliser legs
- Two hydraulic cylinders fitted with single over-centre valves operating the top lifting arms
- Two hydraulic cylinders fitted with double over-centre valves operating the bottom arms
- Four hydraulic cylinders or four hydraulic motors to traverse the cranes (except on Truck mounted and Fixed crane units)
- A solenoid operated dump valve connected to the load sense system (optional)
- A hydraulic pressure gauge

System Control

The system is controlled by a cable remote or the optional radio remote carried by the operator. These have identical ergonomics consisting of a pair of two axis joysticks, a function selector switch, a high/low speed selector switch and an emergency stop button.

System Operation

The tandem pump delivers oil to the high speed load sensed unloader valve, where the two flows can be combined to give high speed operation, or split to give low speed with the second pump flow returning to the oil reservoir.

Also fitted to this valve is a solenoid operated dump valve that is activated by the joystick controllers and the emergency stop buttons.

The pump flow from the high speed Load Sensor (LS) unloader valve passes through the high pressure filter and is divided and supplied to the front and rear control valves. These valves are connected to each other with a load sense line. This helps to maintain synchronisation of the crane lifting arms when unequal loads are handled.

Fitted into the load sense line is an optional solenoid operated dump valve. When the valve is in the de-energised condition load sensed (LS) oil is dumped to tank. When the valve is energised the LS line is blocked to tank and allows the hydraulic system to operate.

A hydraulic gauge is fitted into the LS line and indicates the pressure in the system.



The crane control valves are Danfoss PVG 32 proportional type and are signalled from the joysticks for directional control. High or low speed can be selected at the remote control. The low speed function only applies to the lifting arms. The stabiliser legs are always in high speed irrespective of the position of the high/ low speed selector switch.

Units without Digital Control only (SB360, SE400, some SB330's): When "Low Speed" is selected only one pump is supplying the system and the joystick signals pass via an electronic hydraulic flow (EHF) control and the function speed is reduced by 50% to allow fine control under heavy and difficult loading conditions.

High Speed Load Sense (LS) Unloader Valve Logic

Following is a summary of the logic and function of the "High speed load sense unloader valve".

Speed Mode	"High speed"	"Low Speed"
Operating oil flow	120l/min	60l/min
Operating Pressure	140bar (2000psi) @ HS-LS-U valve	280bar (4000psi) @ Danfoss PVG32
No of pumps operating	2 x Pumps	1 x Pump (second pump to tank)
High speed Solenoid	Energised	De-energised
High Speed relief	140bar (2000psi)	Not Active
Load Sense Solenoid	Energised	De-energised
Load Sense Relief	140bar (2000psi)	Not Active



Hydraulic System - PTO Version

The hydraulic system consists of the following:

- High pressure supply coupling and low pressure return coupling on the front chassis services panel
- High Pressure Filter
- Two Danfoss proportional control valves
- Four hydraulic cylinders fitted with two check valves operating the stabiliser legs
- two hydraulic cylinders fitted with one over-centre valve operating the top lifting arms
- two hydraulic cylinders fitted with two over-centre valves operating the bottom arms
- two hydraulic cylinders or four hydraulic motors to traverse the cranes (except on Fixed and Truck-mounted units)
- A solenoid operated dump valve connected to the load sense line
- A hydraulic pressure gauge

System Control

The system is controlled by a cable remote or the optional radio remote carried by the operator. These have identical ergonomics consisting of a pair of two axis joysticks, a function selector switch, a high/low speed selector switch and an emergency stop button.

System Operation

High pressure oil is supplied via the supply coupling on the front services panel to the high pressure filter, beyond this filter it is divided and supplied to the front and rear control valves. These valves are connected to each other with a load sensing line. This helps to maintain synchronisation of the crane lifting arms when unequal loads are handled. Fitted into the load sense line is a solenoid operated dump valve. When the valve is in the de-energised condition load sensed (LS) oil is dumped to tank. When the valve is energised the LS line is blocked to tank enabling the hydraulic system to operate. A hydraulic gauge is fitted into the LS line indicating hydraulic system pressure.

The crane control valves are Danfoss PVG 32 proportional type and are signalled from the joysticks for directional control. High or low speed can be selected at the remote control. The low speed function only applies to the lifting arms. The stabiliser legs are always in high speed irrespective of the position of the high/ low speed selector switch.

Units without Digital Control only (SB360, SE400, some SB330's): When "Low Speed" is selected only one pump is supplying the system and the joystick signals pass via an electronic hydraulic flow (EHF) control and the function speed is reduced by 50% to allow fine control under heavy and difficult loading conditions.

Pneumatic System

This system comprises the following elements:



- A hold back protection valve
- An engine speed control cylinder (Power Pack only)
- An engine stop control cylinder (Power Pack only)
- Self steer axle (if fitted)

Hold Back Protection Valve

This valve (<http://www.timetemperature.com>) protects the trailer brake system and isolates the auxiliary pneumatic system if the trailer air system drops below a predetermined level as shown in the auxiliary circuit drawing provided.

Crane module locks (applies to R&P Traverse only)

Only sidelifters with Rack and Pinion style Traverse have Crane Module locks.

Two single acting air cylinders are mounted on the underside of the crane lift module between the chassis rails. The cylinders are connected to a plunger style-locking pin that locks the lifting modules in their correct lifting positions. They are spring loaded to lock and air actuated to unlock.

Engine Speed Control

An ON/OFF air solenoid valve when activated by either remote joystick supplies system air pressure to the base end of the speed control cylinder to obtain maximum engine speed (2800rpm). An air pressure regulator supplies a balanced air pressure to the rod side of the speed control cylinder, retracting the cylinder and returning the engine to the idle speed (approximately 1400rpm).

Engine Run/Stop Control

An engine run/stop control solenoid activated by the key switch and emergency stop buttons supplies system air pressure to activate the cylinder. This cylinder requires air pressure for the engine to run and is spring loaded to the stop position.

Self Steer Axle (if fitted)

On Sidelifters with a self-steer axle there is an air supply fitted to the rear axle to control the steering of the self-steer axle. For further information refer to the manufacturer's documents supplied.



Crane Operations

This section covers how to operate the cranes when performing different kinds of lifts.

Operating Near Power Lines



Do not operate a Sidelifter close to power lines.

Electricity supply bodies in each State/Country may have issued regulations or guidelines for the use of cranes in the vicinity of overhead conductors (power lines). The Sidelifter operator must be familiar with these regulations and carry out a site-specific risk assessment prior to the start of any operation where working within close proximity to power lines is required.

All aerial conductors (power lines) must be treated as alive unless the electricity distributor or transmission line operator has stated otherwise. Such a statement must be in writing and include date and time frame of the isolation of the power lines.

The Sidelifter, the lifting arms and the load must be kept at least the listed distances from any power lines during operation:

Voltage	Minimum Distance Required
Up to 500	2.0 metres
500-40,000	4.0 metres
40,000 to 133,000	6.4 metres
Over 133,000	10 metres



Where the above stated minimum distances cannot be achieved, the electricity distributor must be notified in writing and the Sidelifter must not be operated within the minimum distance until the following requirements are satisfied:

For Power lines up to and including 133,000V

- Written permission from the electricity distributor has been obtained
- All conditions specified by the electricity distributor are complied with.
- The electricity distributor is notified before work commences.
- A 'Spotter' performs spotting duties.
- A pre-start site/job meeting has been convened and a risk assessment completed.

For power lines greater than 133,000V

- The electricity distributor has provided an easement entry permit.
- Written permission from the electricity distributor has been obtained
- All conditions specified by the electricity distributor are complied with.
- The electricity distributor is notified before work commences.
- A 'Spotter' performs spotting duties.
- A pre-start site/job meeting has been convened and a risk assessment completed.

Contact with Power Lines (Aerial Conductors)

If the Sidelifter or load contacts power lines, the relevant electricity distributor must be notified immediately. The Sidelifter operator must warn other personnel not to touch any part of the Sidelifter or load and if possible without anyone approaching operate the Sidelifter to break contact.

When unable to move or detangle the Sidelifter from the power line, no further action must be taken until the power is isolated and conditions are confirmed safe.

When a Sidelifter has been in contact with a power line, it must be checked by a suitably competent person and must not be returned into service until all recommended repairs have been completed.








Crane Module Operation - Cable Control

STEELBRO sidelifers have three types of control systems - SMARTlift, Digital Control, and Series 3. Digital control and SMARTlift generally have radio remote controls and the details on how to operate them are in the SMARTlift chapter of this manual. This section details the remote control for the Series 3 control system (SB300 and below, SB360, SE400).




Note that while the operating control systems and their remotes are different, the joystick operations are almost the same.

All operator controls are on the remote control box. This remote control box contains:


- Two joystick controls that operate all lift arm and stabiliser leg operations.
- A two position stay put switch for High  /Low  Speed
- A three position stay put switch to select module traverse , stabiliser leg  and lifting arm  operations.
- A Red "Mushroom" type stop button for Emergency Stop.


As an option the Sidelifter can be specified with radio remote control. Both the cable and radio controls are identical in function.


Sidelifter control valves have detachable manual levers. In the event of an electrical breakdown the operating cycle can be completed manually by using these levers. The levers are stored in tool box.







Arms: 	
Top Arm Up	Joysticks Up
Top Arm Down	Joysticks Down
Bottom Arm Out	Joysticks Out
Bottom Arm In	Joysticks In

Stabilisers: 	
Stabiliser Out	Joysticks Out
Stabiliser In	Joysticks In
Tilt Ram Up	Joysticks Up
Tilt Ram Down	Joysticks Down

Traverse: 	
Module Traverse to 40' position	Joystick Out
Module Traverse to 20' position	Joystick In

Positioning the Lifting Cranes


The process of positioning the lifting cranes should happen in this order:

1. Position the Lifting Cranes in the appropriate positions for the size of container.
 - a) Select Traverse ( or ).
 - b) To move modules out to 40' position, push joysticks out. To move to 20' position, push joysticks in.
2. Position the Sidelifter trailer for lifting the container. Do this second so that, in the instance of lifting a container onto the Sidelifter, it is easier to line the cranes up beside the container.

The furthest apart the Cranes can be positioned is 40 feet, and the closest is 20 feet.



If the Sidelifter has additional positions for one or both of the Cranes, it will be fitted with intermediate stops. In this case the Crane module will need to be positioned on the contact side of the stop yet far enough so the stop can be flipped over. Once the stop has been flipped over the Crane module can be moved until it contacts the stop giving the desired position. See the diagram below.





Lifting a Container From The Ground

On a sidelifter with bending leg stabilisers, refer to the section on how to deploy them before reading the instructions below:






Before performing a lift, ensure the following conditions are met:

Sidelifter must be attached to the prime mover.

Sidelifter park brake is applied.


Ensure that the strength of the ground surface is sufficient to withstand a 27 tonne maximum point loading. If in any doubt, place hardwood timber packing of at least 50mm thick and 200mm x 500mm under each stabiliser foot.

If the stabiliser feet have been placed into a hollow or downward slope then sufficient timber packing will need to be placed under the feet to lift them back up to a level position, if you wish to handle a loaded container.

- Park the Sidelifter alongside the container with approximately 300mm clearance between the container and the Sidelifter.
- Do the following checks:
 - a) Sidelifter twistlocks are directly opposite the container corner castings.
 - b) Sidelifter Brake is applied!
 - c) No hazards and obstructions such as overhanging building awnings, electric power lines or telephone cables.
 - d) Nothing is in the way of the Stabiliser Legs and/or Feet and surface is solid enough to bear them.
 - e) Twistlocks on the Sidelifter are in the raised position and unlocked
- Start the engine and select High speed () operation on the remote control.
- Select Stabilisers ( or ). Extend the stabiliser leg extensions to their maximum then tilt the legs until the feet touch the ground. Do not load feet - Additional pressure will not give additional stability.





Do NOT carry out any lifting if the stabiliser warning lights are flashing unless the load is within the reduced capability as shown on the load chart.

- Set the mode selection switch on the remote control to Arms (). Manoeuvre the top and bottom arms until the chains are positioned centrally to the ends of the container, and fit the lifting lugs into the corner castings of the container, ensuring that there are no twists or tangles in the chains and that the left and right hand lifting lugs are in their correct positions.




Do not try to force the cranes alongside a container. If the lifting arms will not clear the container, the lifting equipment and stabiliser legs should be returned to the stowed position and the sidelifter moved so it will clear the container.

- Take an initial strain on the chains by raising the top arms upwards. Ensure that the lift pins of the crane are in the centre of the container. Choose between the movement of the top and bottom arms to centralise the lift pins. Take the weight of the container and check that the Sidelifter is stable with the weight being lifted.
- Select Low Speed ( or ) on the remote control.
- Lift the container approximately 150mm (6in) off the ground by raising the top arms. In the event that the container is lifting unevenly it may be necessary to operate one end only to bring the lower end of the container up to a level position. Move the container, just above the ground, towards the Sidelifter, until it is about 300 mm from the side of the Sidelifter
- Raise the top arms until the bottom of the container is level with the top of the Sidelifter chassis.
- Lower the bottom arms until the container corner castings are above their respective twistlocks.



Rapid starting and stopping movements are stressful on the equipment, and may cause the container to swing, which may damage the cranes and twistlocks. To ensure smooth movement, feather the controls in and out of operation.

- Lower the container down onto the twistlocks by locating either front corner onto a Twistlock cone, and then the rear visible corner onto its Twistlock cone. With practice operators will be able to land the containers onto the twistlocks in one smooth operation.
- Select high speed () and lower the lifting arms to their stowed position.
- Select Stabiliser Mode and return the stabiliser legs to their stowed position.
- Stop the engine, turn the key off and stow the controls. (cable remotes: Avoid twisting and knotting the cable.)
- Lock the twistlocks.

The Sidelifter can now be driven to the unloading site.



Placing a Container on The Ground



Before performing a lift, ensure the following conditions are met:

Sidelifter must be attached to the prime mover.

Sidelifter park brake is applied





Lifting area complies with safety zones recommended on decal and is clear of any obstructions

The ground beneath where the stabilisers will be deployed is firm and can withstand up to 1.7Mpa of pressure. If not, placing packing under the feet as described in previous section.

- Park the Sidelifter alongside the area where the container is to be placed, ensuring that conditions above are all met.
- If they are not already attached, attach the lifting chains to the container.
- Unlock the twistlocks.



Ensure the twistlocks are unlocked prior to lifting

- Start the engine. Select High speed () on the High/Low Speed Switch.
- Fully extend the stabiliser legs and place the feet on the ground.
- Raise the top and bottom arms until the chains are evenly tensioned.
- Select low speed ( or ) on the remote control.
- Raise the top and bottom arms to lift the container clear of twistlocks.
- Move the container across the chassis until the container is 300mm clear of the side of the Sidelifter.
- Lower the top arms to place the container on the ground. If it is necessary to move the container further out from the Sidelifter, do this with the container no more than 150mm, (6in) above the ground.
- Once the container is placed firmly on the ground, slacken the lifting chains and remove the lifting lugs from the container.
- Switch to high-speed operation () and return the lifting arms to the stowed position, ensuring the lifting chains are in the chain trays beside the twistlocks.
- Return the stabiliser legs to the stowed position. It is also good practice to fully stow cranes when transporting containers between facilities.
- Stop the engine, turn the key off, and stow the controls.



Transferring Containers to and from a Truck or Trailer



Ensure that the spacing between the vehicles is such that the stabiliser foot is able to reach the centre line of deck on companion truck or trailer. Always refer to stability chart before commencing lift.

Follow the procedure as described previously for loading to and from the ground:

a) Stabiliser leg placed on deck or chassis

Where the deck length permits, legs should be placed on top of the companion truck or trailer. If the deck of the companion truck or trailer has been designed for operating with a STEELBRO Sidelifter, position the stabiliser foot in the designated area. Alternatively place the Stabiliser feet with care, ensuring that the point of contact is strong and stable enough to bear the weight of the lift. Timber dunnage may help to distribute the weight load.

b) Stabiliser leg placed on ground

If there is insufficient room to place the feet on the deck they can be placed on the ground.

Park the two vehicles approximately 1 metre apart. Place one leg on the ground at the rear of the companion truck. Place the other leg as far as possible under the front of the companion truck on the ground. Longer truck decks can be treated as per transferring 20' containers onto 40' trailers.

Transferring 20' Containers to and from 20' Trailers or 40' Containers to and from 40' Trailers

Follow the loading to and from the ground procedure except:

- Park the two vehicles approx 1 metre apart, with twistlocks aligned.
- Place one stabiliser leg on the ground at the rear of the companion trailer.
- Place the other stabiliser leg on the ground under the tractor unit chassis, if it can be placed there fully extended without obstruction. If not, jack-knife the companion tractor unit to 45 degrees enabling the stabiliser leg to be placed on the ground fully extended in front of the companion trailer.



Always ensure the twistlocks on both vehicles are unlocked before commencing transfers.

Transferring 2 X 20' Containers To and From 40' Trailers

Follow loading to and from the ground procedure except:

- Load the first container onto the front of the 40' trailer in the most forward position achievable and lock the twistlocks.



- Sidelifter lifting lugs can be fitted into the outside hole of the corner castings of containers. This allows handling of tightly spaced containers.
- Load the 2nd container onto the rear set of twistlocks, with the centre pair of lifting lugs fitted to the outside as described above. Lock the front twistlocks only of this set. Lift the rear of the container slightly to ensure maximum spacing. Lower and lock the rear twistlocks. As 20' containers are actually only 19'-10" sufficient spacing can be gained for chain clearance using this method.

Double Stacking Containers

Double stacking is where one container is placed on top of another, to save floor or ground space. We recommend that operators receive training in this technique before attempting it themselves.

This topic explains how to double stack and unstack.



Do not place a 20' box on top of a 40' box or a 40' box on top of a 20' box.
No anti slip protection is provided on the legs. If you use them as an access platform you do so at your own risk.



Do not use sidelifter lifting chains in the top castings of the ISO container as this may cause severe damage to the machine, and place personnel at risk. Any such action will void our warranty. Top lifting should only be attempted with a top-lifting frame.

Double Stacking - lifting container from sidelifter to place on top of another container.

1. Shorten the chain assemblies in accordance with the relevant "Chain Shortening Instructions" and attach to container.
2. Load container onto sidelifter.
3. Position the Sidelifter 300-600mm from the side of the container on the ground with the ends parallel.
4. Fully extend the stabiliser legs and place the feet on the ground. Packing needs to be placed under the feet in soft or doubtful ground.
5. Raise the container off the Sidelifter, within the area as described above, to clear the top of the container on the ground. To do this, follow these steps:
 1. Move the bottom arms OUT until the lifted container almost touches the container on the ground.
 2. Raise the container vertically (be very careful not to allow the container to move over the offside/non lift side) until the lifted container clears the top of the container on the ground.
6. Keeping your lifted container low, move it out across the top of the container on the ground.



7. Align the corner castings of the bottom and the top containers, release and remove the lifting chains, and re-stow the cranes.


Unstacking - lifting top container back onto sidelifter.

1. Shorten the chain assemblies in accordance with the relevant "Chain Shortening Instructions"
2. Position the Sidelifter 300-600mm from the side of the container on the ground with the ends parallel.
3. Fully extend the stabiliser legs and place the feet on the ground. Packing needs to be placed under the feet in soft or doubtful ground.
4. Connect the lifting chains.
5. Gently lift the container as it may swing a little when first lifted. Once the container is lifted and is stable, move it in across the top of the container on the ground towards the sidelifter.
6. Bring the lifted container in towards the sidelifter until it is just clear of the container under it. Start to lower and manoeuvre the container towards the sidelifter until it is just above the twistlocks (be very careful not to allow the container to move over the offside/non lift side.)
7. Once the container is back on the twist locks it will be necessary to completely lower the top arms and then the bottom arms, to get the container to sit on the twist locks. This will also help to keep the weight on the stabilizer legs.
8. Stow the cranes and the stabilisers.


The sidelifter is ready to be moved and the container can be removed as per procedure for unloading a container from the sidelifter to the ground.

Chain Shortening Instructions 20mm Chain

Counting the link that is attached to the hammerlock, place the appropriate link (see table below) in the slot provided in the "chain shortener." Check all four chains are equally shortened before lifting container.



20mm Clevis Style Chain shorteners



20mm Oblong Loop Style Chain shorteners




Check all four chains are equally shortened before lifting container.


Model	#links counted from the hammerlock)
SB360	17
SB360 (with extended arm)	14
SE400	9
SB401	9

Chain Shortening Instructions 16mm Chain

To shorten the chains, follow these instructions.



- From, and including, the first free link below where the chain shortener is joined into the chain (A), count down the appropriate number of links (see table below)
- Holding the chain so it is slack, slot the link into the pocket of the chain shortener.
- Pull it down to ensure it is seated properly. If required, depress the spring loaded securing bolt (3). Securing bolt locks automatically. Check locking.
- Check all four chains are equally shortened before lifting container.
- To release the chain again, reverse the procedure, depressing securing bolt at the same time.



Model	# links counted from shortener
SB300	13
SB330	13
SB360	11
SB361	11



Transferring Containers to & from Rail Wagons

If the containers are spaced (i.e. there is sufficient room at either end to place the stabiliser leg onto the rail wagon) and there is access to the bottom corner castings, then these transfers can be done in the same manner as trailer transfers.

If there is insufficient access to the corner castings of the containers to allow the lifting lugs to be attached then a Top lift frame will be required.

If the stabiliser legs cannot be placed onto the rail wagon, it is necessary to park the Sidelifter to allow the stabiliser feet to be as far as possible underneath the wagon, with the legs extended to their maximum.



Do not place stabiliser feet on rail tracks. Feet must be placed on level surface.



Recommended Companion Vehicles

STEELBRO have noticed that many Sidelifter operators are not aware of the ways in which specifying other transport equipment can help their Sidelifter operations.

We have therefore set out some points that may be helpful when you are purchasing other new equipment.

1. When buying 12.5 metre or longer semi trailers we recommend an extra set of twistlocks to allow wide spacing of two 20' containers i.e. An extra set of twistlocks at the front or rear outside the existing 40' set to give Sidelifter arm access when two 20' containers are carried.
2. When specifying truck flat-decks we recommend a space of 215mm between the Twistlock centres and the headboard. This allows sufficient room to fit the lifting lugs to the container. A further consideration is that if you buy a mini Sidelifter for handling empty containers then a space of 800mm will be required.
3. When buying drop deck container trailers, we recommend a space of 215mm between the drop in deck, and the Twistlock centres, to allow sufficient room to fit the lifting lugs to the container.
4. When setting up Tractor units for use with a semi trailer to be loaded or unloaded by the Sidelifter, appropriate reinforcing across the chassis rails of the tractor unit enables the Sidelifter to put a leg on this reinforcing rather than uncoupling or jack-knifing the tractor unit.



Maintenance

Why Genuine Parts?

When you or your service workshop carry out service or repair work on your STEELBRO Sidelifter, it is important that you fit genuine STEELBRO Sidelifter Spare Parts.

The STEELBRO Sidelifter is a product of high technical standard. A guarantee that this quality will continue throughout the life of the Sidelifter requires that it gets regular service and that only genuine spare parts are used.

Preventative Service

The following section describes the service and maintenance requirements of the Sidelifter. All components must be checked regularly for proper functioning and adjustments made only if necessary. Before the Sidelifter left the factory, every valve in the hydraulic system was thoroughly tested and properly adjusted and the complete unit was test operated at full lifting capacity. A duly competent person must carry out all servicing and any subsequent adjustment.



When using a steam cleaner on the Sidelifter, avoid cleaning near hydraulic cylinder shafts, electrical control boxes or junction boxes and switches. While the latter are fully water proofed, they may not tolerate hot steam cleaning jets.

Grease and Oil Specifications

The hydraulic system and the hydraulic fluid are matched in respect of lubricating performance, effect on seals, and non-compatibility with other materials. For this reason do not mix different types of hydraulic fluid, such as mineral oils, synthetic fluids and water based fluids, and never adulterate your hydraulic fluid with diesel oils or alcohol based products.



We recommend the use of non-molybdenum based greases as these do not deteriorate the crane bushings.

Use	Recommended Product
▪ Hydraulic Oil	-Castrol Hyspin AWS46 or equivalent*
▪ Bearing Grease	-Shell Alvania EP or equivalent



▪ Hub Grease	-Shell Alvania EP2 or equivalent
▪ Hub Oil	-Castrol Multitrax 80w/140 or equivalent
▪ Wheel Stud Grease	-Shell Alvania EP2 or equivalent

* May vary for different markets depending on temperature range:

Temperature Range	Recommended Product
From -20°C to +30°C	Castrol Hyspin AWS 32
From -10°C to +40°C	Castrol Hyspin AWS 46
From 0 to 50°C	Castrol Hyspin AWS 68

Servicing Trailer Running Gear

For servicing detail refer to the Suspension and Axle Manuals.

Records

All checks, adjustments, replacement of parts, repairs and inspections performed, and all irregularities or damage potentially affecting the Sidelifter's safety should be recorded in an orderly manner. In some countries this is mandatory.

A STEELBRO comprehensive service programme is available through your distributor. As this is designed specifically to support the safety, operation and maintenance requirements of your Sidelifter, we recommend that you contact your distributor for more information if you do not already have this programme in place.

For your convenience, a service programme summary logbook is provided.

Daily Inspection Requirements

Hydraulics

- Check the engine oil and water levels.
- Check the oil level in the hydraulic reservoir. (The oil level needs to be between the "Max" and "Min" levels on the sight glass when the Sidelifter is in the stowed position). Check pump suction line shutoff valves are open.
- Check that the lifting arms and stabiliser legs can be operated with ease and that the controls automatically return to the neutral position.
- Inspect the hydraulic lines, connections and other components to detect any oil leakage or damage. Tighten any loose or leaking connections.



Warning: Ensure that when connecting Quick Release Couplings, the low-pressure line is always correctly fitted before fitting the high-pressure line.

When disconnecting hydraulic tubing and hoses, always ensure that no hydraulic pressure has been retained in the line after the power supply to the system has been switched off.

Refer to Precautions with Over-Centre Valves and Check Valves (on page 65)

Lifting Gear and Chassis

- Check the lifting chains, lifting lugs, hammerlocks and other components of the chain assemblies to ensure that they are not damaged. The hammerlocks should be able to fold otherwise they have been overstressed and are in need of replacement.
- Check the Sidelifter, chassis and twistlocks for damage. For example, check that the container guides on the far side of the crane bases are present and not unduly bent or deformed.
- Inspect the lifting module sliding areas on top of the main chassis for cleanliness.

Brakes - Air Pressure Systems

- Run the truck engine to achieve maximum air system pressure. Stop the truck engine and check the truck air gauge does not show a rapid loss of pressure that would indicate an air leak.
- Apply and release the brake pedal twice. Air pressure should not drop abnormally when brakes are applied. Check that the brakes release immediately. Check that the slack adjusters on the trailer axle camshafts do not have excess movement that indicates brake adjustment is required.
- Check that all hoses are firmly connected and that there is no damage caused by cuffing or knotting.
- Vent air reservoirs to expel condensate by using the drain valves.

Lights

- Inspect switches and lights for broken brackets, fused bulbs and cracked lenses. Check for loose wiring connections - usually indicated by flickering, dull or intermittent lights.
- Clean light lenses and reflectors.

Wheels and Tyres

- Check tyre pressures are correct, check that the valves are not damaged and trailer axle dust covers are in place.
- Remove all objects trapped in the tyre tread and ensure tread depth complies with road regulations.
- Ensure tyres have no cuts or bulges.
- Examine all wheels for damage caused by "kerbing" or severe road shock.
- Check that the wheel nuts are properly seated and show no signs of running loose.



- Check oil level in the axle hubs is between the minimum and maximum levels if the axles are of the oil filled type.



WARNING: After any removal and refitting of any wheel with ISO wheel nuts, ensure nuts are re-tightened within 50 to 100km of travel. Neglecting to do so could result in loss of a wheel.

Suspension

- Check springs for shifting or missing leaves, loose or missing clips and any damage.
- Check suspension U- bolt, bearings and bushes for security and condition.
- Check air bags for damage, chaffing etc.



Weekly Inspection and Service Requirements



Perform all activities required for daily and weekly inspections and in addition carry out the following service procedures

Chassis

- Grease all grease nipples on the chassis, brake slack adjusters and landing legs with Shell Alvania E.P. grease.
- Grease semi trailer rub plate and kingpin with a good quality hub grease.
- Clean down lifting module sliding areas on top of main chassis and then wipe over with clean cloth.



Grease points are detailed on the lubrication chart in this manual.

Lifting Modules

- Grease all lifting arms and cylinder pivot bearings at front and rear.
- Check all pivot pin keeper plates and circlips for security.

Landing Legs

- Check landing legs for damage and serviceability.

Monthly Inspection and Service Requirements

Perform all activities required for daily and weekly inspections and in addition carry out the following service procedures:

Hydraulic System and Chassis

- Check all bolts on the Sidelifter, particularly pin keeper plates around the power pack if there is one, and the combined hydraulic reservoir/fuel tank mounting. Tighten any loose bolts.
- Check the Sidelifter operator notices are in place.



- Check the lifting arms and stabiliser legs to detect any visual signs of damage, deformation or wear in the bearings.
- Service engine air filter and change as required.
- Check the Emergency Stop button and the electrical safety devices.

Brakes - Air Pressure Systems

- Check that the linkages on the trailer axle camshafts do not have excessive movement. If so adjust brakes in accordance with brake servicing instructions.
- Listen to air system for any noise of an air leak and tighten any loose connections.

Lights

- Check all cables are firmly connected and not damaged by scuffing or pinching.

Wheels and Tyres

- Check wheel bolt/nut torque settings as detailed in axle manual



WARNING: After any removal and refitting of any wheel with ISO wheel nuts, ensure nuts are re-tightened within 50 to 100km of travel. Neglecting to do so could result in loss of a wheel.

Six Monthly Inspection and Service Requirements

Perform all activities required for daily, weekly and monthly inspections and in addition carry out the following service procedures:

Hydraulic System

- Check all hydraulic hoses and pipe work for wear, scuffing and fretting
- Check the mountings of the hydraulic reservoir for condition and security.
- Change the following filters (where applicable):
 - Engine oil
 - Engine fuel
 - Hydraulic oil tank
 - Hydraulic oil pressure
- Change the oil in the power pack
- Clean the hydraulic tank breather element



- Change the hydraulic oil if required. If water contamination is present oil should be changed. See hydraulic oil change guide at the end of the maintenance section of this manual.
- Check fan belt tension
- Check condition of radiator hoses.
- Check engine coolant for condition as detailed in Kubota Operators Manual.



NOTE: For detailed instructions on power pack routine required maintenance, refer to The Kubota Engine Operators Manual.

Chassis

- Disconnect the tractor unit from the trailer and check the king pin for wear and security of attachment.
- Thoroughly clean the Sidelifter.
- Check chassis components for signs of stress, damage, cracking, corrosion etc.



CAUTION: Avoid spraying the chrome shafts of the hydraulic cylinders with water blaster or system cleaner.

Suspension and Axles (As detailed in the suspension and axle manuals)

- Carry out brake servicing
- Check out suspension servicing
- Check axle alignment
- Check nut torque settings

Annual Inspection and Testing

Perform all activities required for daily, weekly and six monthly inspections and in addition carry out the following service procedures:

King Pin

The king pin connecting the Sidelifter to the tractor unit should be crack tested or renewed. The latter is often the cheaper alternative. This check is required by automotive testing stations in N.Z., and is recommended to all Sidelifter owners because of the stresses applied when lifting loads.



Lifting Chains

Remove both lifting chain assemblies, and inspect and measure, as per the PWB Herc-Alloy Chain Recommendations. Each country has its own requirement for inspection and testing of lifting chains and slings. These must be adhered to. STEELBRO recommends that chains are proof tested annually and that the records are retained for history.

Lifting Equipment

Carry out a full monthly and six monthly inspection, and pay particular attention to the lifting arms, stabiliser legs, and their mountings for any signs of cracking, or other damage. Check top arm lifting pins for wear by ensuring the pins can be rotated in their bearings. Check the emergency stop and the electrical safety devices.

Overload Test

After all other checks have been completed; carry out a 10% overload test:

The load should be 10% of the maximum load shown on the lifting chart, eg. 30,000kg + 3,000kg = 33,000kg.

When lifting off the Sidelifter, keep the test load close to the Sidelifter.

Carry out test at 300mm clearance from the Sidelifter side rail (i.e. 2800mm from Sidelifter centre line).

Testing after repairs to the cranes



No modification may be carried out on the Sidelifter without written authorisation from STEELBRO. Unauthorised modifications automatically void all warranties and service agreements.

After repairs on the crane and before putting it back into use, an OVERLOAD TEST must be carried out as described in the previous section.

Maintenance Notes

Pressure Line Filter:

This filter is of the full flow type with a bypass valve fitted. It has a replaceable element and this should be changed after the first 50 hrs of operation and thereafter at every 200 hours or six months.

Return Line Filter:

This filter is of the full flow type with bypass and should be changed at the same intervals as the Pressure Filter.



Filler Breather:

One filler breather is on the hydraulic oil reservoir.

The filler cap breather gauze of this unit needs washing out with cleaning solvent and blown dry with compressed air every 500 hrs or 6 months or as required particularly if operating in dusty conditions.

The strainer gauze in the tank aperture should be checked for condition and cleaned as required. Ensure the gauze is intact and no splits or damage is evident.

Emergency Instructions in Case of Electrical Faults:

The PVG control valves are fitted with manual operating handles for emergency or servicing use. In the event of an electrical fault in the control system, they can be used independently to complete the loading or unloading of a container.



NOTE: The plug on the affected solenoid will have to be disconnected before manual control can be operated as the valves are held in neutral with the electrical system connected.

Precautions with Over-Centre Valves and Check Valves

Cylinders, fitted with Check Valves and or Over-centre Valves, can remain pressurised. The pipes connecting the 'B' port to the Check/Over-centre Valve Block Assembly, mounted to the 'A' port, can remain pressurised.

To relieve the pressure in these systems carry out the following steps.

For units fitted with Over-Centre Cartridges:

Slacken the adjustment lock nut and relieve the cylinder pressure by turning the adjustment screw anticlockwise until no resistance is noticeable (about 5 full turns).

The Over-centre Cartridge can now be screwed outward to a point where the sealing surfaces are separated thus guaranteeing no pressure remains trapped in the cylinder or pipe work.



Notes On Tractor/Semi Trailer Operation

Coupling and Uncoupling

Periodically check that coupling jaws or hook locks are free, working easily and are well lubricated. If the main plate is covered with road dirt and grit, clean off with solvent and re-lubricate with a good quality grease (hub grease is ideal).

Regularly inspect tractors and trailers for damage to couplers, kingpins and pick-up plates, caused by violent impact.

We recommend this, as it is the practice of some drivers to back up to trailers too fast, when coupling.



Undetected damage resulting from the careless and dangerous habit of backing up to the trailer too fast can endanger life and goods.

Experience Counts

Everyone connected with articulation is familiar with the sound of a tractor being coupled to a trailer - but it is difficult to draw a line between the firm, positive "clunk" and an impact between tractor and trailer severe enough to cause damage.

Chief Cause of Trouble


Coupling heights of loaded trailers when parked will vary due to many operating factors, such as difficult road or yard surfaces. Fleet surveys have shown that most damage is caused by attempting to couple up units that are unsuited in terms of coupling heights.

Many of the older tractors have rear springs with a high deflection rate, and when uncoupling a loaded trailer, the landing gear is wound down at the loaded height. As the tractor moves away from the trailer, the tractor springs rise to the unladen position. Thus, when re-coupling, the tractor springs have to be forced down to permit the fifth wheel to pass under the trailer plate. This action requires considerable effort, but if the driver uses too much power, an excessively violent coupling takes place. Damage is often caused to the trailer plate in this way and periodic checks should be made to ensure that the plate is not distorted and that the kingpin is square to the face of the trailer pick - up plate.

Damage can also be caused to the coupler throat, and spreading of the hook jaws, if the trailer is too high for the tractor unit. The surfaces of the trailer pick up plate and fifth wheel coupler should be in contact to obtain correct connection.



Drawing showing a typical damage and misalignment of kingpin caused by an excessively violent coupling of tractor and trailer:



Simple Checking Devices For Semi Trailers

The plate and kingpin can be checked very quickly by using a straight edge. This can be any straight flat piece of metal or timber with an appropriate rectangular section cut out to clear the kingpin.

Place the straight edge across the trailer plate, first across the trailer and then longitudinally, and you will soon see any bow or distortion in the plate. Also by having a cut-away rectangular shape square to the flat edge, any damage or misalignment of the kingpin can be seen. The cut-away portion should be made to the correct depth - the same as the kingpin depth - thus serving to show that the kingpin has not been forced upwards, which would probably impair the coupling mechanism.

To check the tractor coupling, it's a good idea to use part of an old plate of convenient size with a kingpin mounted in position. This way the coupling action can be simulated. When coupled, the pin should be held firmly and snugly without slack.



Index

A

Annual Inspection and Testing • 63

B

Bending Leg Option - for SB360, SB361 and SB401 • 22

Brakes - Air Pressure Systems • 59, 62

C

Chain Shortening Instructions 16mm Chain • 51

Chain Shortening Instructions 20mm Chain • 50

Chassis • 61, 63

Chassis, Suspension & Axles • 17

Chief Cause of Trouble • 67

Commissioning Checks • 12

Commissioning the Sidelifter • 13

Contact with Power Lines (Aerial Conductors) • 40

Coupling and Uncoupling • 67

Crane Lifting Modules • 25

Crane module locks (applies to R&P Traverse only) • 15, 38

Crane Module Operation - Cable Control • 41

Crane Operations • 33, 34, 39

Crane Traverse Safety • 9

D

Daily Inspection Requirements • 58

Design and Modifications • 3

Double Stacking Containers • 49

Driving Safety • 8

E

Electrical System - PTO Version • 34

Electrical System Power Pack Version • 33

Emergency Instructions in Case of Electrical Faults: • 65

Emergency Stop Button • 10

Engine Run/Stop Control • 38

Engine Speed Control • 38

Experience Counts • 67

F

Filler Breather: • 65

Foreword • 1

G

General Description • 11

Grease and Oil Specifications • 57

Ground Pressure • 19

H

Health & Safety Compliance • 3

High Speed Load Sense (LS) Unloader Valve Logic • 36

Hold Back Protection Valve • 38

How to Operate the Bending Leg • 23

Hydraulic System • 10, 62

Hydraulic System - Power Pack Version • 35

Hydraulic System - PTO Version • 37

Hydraulic System and Chassis • 61

Hydraulics • 58

K

King Pin • 63

L

Landing Legs • 61

Lifting a Container From The Ground • 45

Lifting Chains • 64

Lifting Chains - Clevis Hook (SB330, SB360, SB361 and SB401) • 26

Lifting Chains - Oblong Link/Top Hook (some SB330's and SB360's) • 27

Lifting Equipment • 64

Lifting Gear and Chassis • 59

Lifting Lug Instructions • 8, 29

Lifting Modules • 61

Lifting Safety • 7, 8

Lights • 59, 62

M

Main Components • 15

Main Components Fixed Module Models • 17

Maintenance • 57

Maintenance and Servicing • 3

Maintenance Notes • 64

Modifications • 10

Monthly Inspection and Service Requirements • 61



N

Notes On Tractor/Semi Trailer Operation • 67

O

Operating Near Power Lines • 39

Operation • 20

Operator Safety • 5

Over-Centre Valves • 25

Overhead Power Lines and Cables • 7

Overload Test • 64

Owner and Operator Responsibilities • 3

P

Placing a Container on The Ground • 47

Pneumatic System • 37

Positioning the Lifting Cranes • 42

Power Pack • 30

Precautions with Over-Centre Valves and
Check Valves • 59, 65

Pressure Line Filter: • 64

Preventative Service • 57

Proximity Switches (units without SMARTlift
only) • 19

R

Recommended Companion Vehicles • 55

Records • 58

Regulation Compliance • 3

Return Line Filter: • 64

S

Safety Controls - SB361 and SB401 only • 24

Safety Instructions • 5

Self Steer Axle (if fitted) • 38

Servicing Trailer Running Gear • 58

Shift Safety Practices • 5

Simple Checking Devices For Semi Trailers •
68

Six Monthly Inspection and Service
Requirements • 62

Stabiliser Interlock System • 20

Stabiliser Legs • 6, 18

Suspension • 60

Suspension and Axles (As detailed in the
suspension and axle manuals) • 63

System Control • 35, 37

System Lay Out • 33

System Layout • 34

System Operation • 33, 34, 35, 37

T

Testing after repairs to the cranes • 64

Tractor Unit Safety • 5

Transferring 2 X 20' Containers To and From
40' Trailers • 48

Transferring 20' Containers to and from 20'
Trailers or 40' Containers to and from 40'
Trailers • 48

Transferring Containers to & from Rail
Wagons • 53

Transferring Containers to and from a Truck
or Trailer • 48

U

Using the Container Lifting Lugs • 29

W

Weekly Inspection and Service Requirements
• 61

Wheels and Tyres • 59, 62

Why Genuine Parts? • 57

Work Area Safety • 7