



SL0006 SMARTlift PIN Numbers

SL0006	Version 1	SMARTlift	15-07-05
--------	-----------	-----------	----------

System Override Pin No's

Single Lift Manual Override Code 1970

Note: This PIN number should only be used in the event of a unexpected system condition which results in a 'lock-out' condition, this bypasses the safety system for one lift only.

The SMARTlift system records the date and time of every use of this PIN Number.

Distribution: Operators via authorisation from their dispatch

Authorised Service Agents

Permanent Manual Override Code 2004

Note: This code should only be used in the event of a system failure, like a faulty sensor which prevents the system operating correctly. This PIN number can be used while spare parts and technical assistance are sourced. The use of this PIN number bypasses the safety system until the Manual Override Reset Code is entered. The SMARTlift system records the date and time of every use of this PIN Number.

Distribution: Authorised Service Agents Only

Manual Override Reset Code 9999

Note: This code is used to RESET the Permanent Manual Override Code in order to reactivate the SMARTlift LM System after repairs. The SMARTlift system records the date and time of every use of this PIN Number.

Distribution: Authorised Service Agents Only

Crane Synchronisation Access Code 1112

Note: This code is used when the cranes need to be re-synchronised

Distribution: Technicians who have been trained in the correct procedure

Authorised Service Agents

Refer to Service Letter Lett0021_1GB for Manufactures Area Code