

## Additional Information On Smartlift Display.


### Description

A new page has been added to the display which shows:


- The software and revision in the Front Crane
- The software and revision in the Rear Crane
- The software in the display.

### Details

#### New Information – Front Page



#### New Information - System Info Page



(Note: See TB0083 for detail on the software parts numbers)

## Additional Information On Smartlift Display.

### How to access the System Info Page

Accessing the system info page is done via the Manufactures Area page. No password is needed to access the system information.



Select "View System Info" to access the system information page.

## Models and Markets

All smartlift and DC system fitted with display and crane software that has the SW prefix.

If the new display software is loaded onto old crane software then the Model in the front page, rear crane version in the system page will be displayed correctly. All other details will be displayed as "\*\*\*\*\*". This will not affect the functionality of the machine.

## Installation

There is no change in reprogramming the units in the field.

Download the software as per "SL0003 Updating LCD Display Pages V2"

## Backward Compatibility

Software for screens with TOS 191 is v1xx . (See TB0081 for more details)  
Software for screens with TOS 393 is v2xx

## Advantages

Easier to identify which software is loaded in the system.